

**Note(s):**

1. Install ground wire only where specified on the working drawing.
2. When specified on working drawing, bring telephone company bond wire into structure the same as shown for ground wire. Extend bond wire to ground rod or bar and attach. (Telephone company to furnish bond wire and clamp.)
3. One ground rod is required only in pull boxes where primary cables are installed.
4. Ground rods and ground wire, when required, are furnished by the contractor. Contractor will install all grounding materials required.

<b>AC 700</b>		<b>Ground Rod — Ground Wires</b>	Approved by: <i>PHH</i>
Sheet 2 of 2		What's Changed?	Effective Date: 10-28-2005
<b>UGS</b>			