

**NOTES:**

1. GALVANIZE ALL STEEL AFTER FABRICATION.
2. USE STAINLESS STEEL MOUNTING HARDWARE. USE WASHERS, SPLIT-LOCK WASHERS UNDER ALL NUTS AND BOLTS.
3. CONCRETE ANCHORS, SEE SPECIFICATIONS SECTION 05 50 00.

TRANSFORMER

NTS

© CH2M HILL

2622-004