



#### NOTES:

1. PLACE PREMOLDED FILLER AGAINST VERTICAL FACE WHERE VALLEY GUTTER ABUTS CONCRETE.
2. CONSTRUCT 6" x 3" DEPRESSED BENCH WHERE VALLEY GUTTER ABUTS ASPHALT PAVEMENT.
3. WHEN BENCH IS NOT REQUIRED, CONSTRUCT 1" BATTER ON VERTICAL FACE.
4. PROVIDE 3" MINIMUM COVER ON ALL REINFORCING STEEL.

## CONCRETE VALLEY GUTTER

NTS

© CH2M HILL

3216-330