

water facts 1

Ground Water in Fractured Hard Rock

water.ca.gov/publications

California Department of Water Resources
Attn: Publications Office
P.O. Box 942836
Sacramento, CA 94236-0001
(916) 653-1097
imr-publications@water.ca.gov

Free
01/11

In mountainous areas of California, groundwater can be found in the cracks or fractures of hard rocks, such as granite, greenstone, and basalt

The water does not actually penetrate the rocks, because there is no pore space between the grains of the rock. However, some of these rocks have fractures in them. These fractures store water and yield small amounts of water to wells that intersect the fractures.



Some sedimentary rocks, like sandstone, are hard but can still absorb some water into their pores. These rocks may also have fractures that contain water.

About 60 percent of California is composed of hard rocks. However, only a small quantity of groundwater is stored in the fractures of these rocks.

The majority of groundwater is stored in what the average person would call "dirt" or "soil," more accurately described as alluvium (loose gravel, sand, and silt) which has pore spaces between the grains.

Where are the hard rocks?

In general, all mountain and hilly areas of California are composed primarily of hard rocks.

- The Coast Ranges, The Sierra Nevada, and large areas of coastal southern California and southern desert regions consist of granitic and metamorphic, volcanic, and hard sedimentary rocks.
- The northeastern part of California is composed mainly of volcanic rocks.

A thin layer of sediments, soil, or weathered rock covers some of these hard rock formations.

How do rocks become fractured?

Like most fractures, rock fractures are caused by stress. Rocks may fold, faults may move, and rocks may expand when overlying material is removed by erosion and the now-bare rocks are exposed to the weather. Volcanic rocks may also fracture while cooling and contracting. Ice, plant roots, or water flow can enlarge these fractures.

What do the fractures look like?

Fractures may be large or small and may run up and down or sideways. They may be a few millimeters to hundreds of meters long, and range in width from less than a millimeter to several centimeters, but usually occur in a regular pattern.

In carbonate rocks (limestone and dolomite) the fractures may be enlarged into caverns when the rock is dissolved by water.

You'll find most fractures in the upper few hundred feet of rock. This is because the weight of the rock on top inhibits the development of deep fractures. In addition, the deeper you go, the smaller the width of these fractures.

The beautifully sculpted rocks that form Yosemite Valley are the result of glaciation and the removal of rock material along these intersecting fracture surfaces.

How does water get to the rock fracture?

Water that falls on land may run off on the surface in creeks and rivers, or it may infiltrate into the rock materials on the ground. The infiltration of water recharges groundwater

supplies in sandy, loose material and in fractured hard rock.

It is important to note that water occurring in rock fractures have less protection from contamination, compared to alluvial aquifers where the soil acts as a filter treatment.

Why are fractures important for groundwater?

For the most part, fractures are the only way groundwater can be stored in hard rocks. In addition to relatively small amounts of storage, the fractures (particularly intersecting networks of fractures) are the primary conduit for groundwater flow to wells.

Variables that affect water volume:

- size and location of the fractures
- interconnection of the fractures
- amount of material clogging the fractures

Water can also be stored in lava tubes in volcanic rock and in solution openings in carbonate rocks (limestone and dolomite).

How much water is stored in hard rock?

The total volume of water stored in fractured hard rocks near the surface is estimated to be less than 2 percent of the rock volume. This percentage decreases with depth as fractures become narrower and farther apart.

The amount of water in the rocks surrounding a hard rock well is small. Groundwater levels and the well's yield can decline dramatically during the summers of dry years.

In areas where alluvium overlying the hard rock is saturated with water, the alluvium provides additional water storage for nearby wells in the hard rock. The volume of water stored in many alluvial soils can amount to 10-25 percent of the volume of the alluvium. This situation most often occurs in valleys or meadows.

How much water will my well yield?

Half of all hard rock wells yield 10 gallons per minute or less, which is only enough for individual domestic supplies. When conditions are good, wells drilled in fractured rock may yield several hundred gallons per minute when pumped.

Good conditions:

- large amounts of fractures
- good interconnection between fractures
- wide, large, clean fractures
- a source of recharge
- a large quantity of water in storage
- proper installation of the well, including removal of granular debris that may clog the fractures

Some wells may be dry if the above conditions are not met.

How do I know I have a high-yielding well?

You don't. While exploration of the well site may help, you will still face some trial and error that you seldom face when drilling in an alluvial aquifer.

Wells that are close together in alluvial aquifers will probably have similar yields. However, hard rock wells may not have similar yields. You have to be able to drill to a very specific point in a major fracture zone that has a lot of water in it. The water must also be continuously recharged. If these conditions aren't met, then you can easily have a dry hole that is drilled right next to a producing well.

Also, keep in mind that a neighboring well can interfere with your well. How much water passes through fractured rock varies greatly depending on connections between fractures. As a result, interference between neighboring wells is difficult or impossible to predict in advance. The best insurance against such problems is large lot sizes. Wells on lots as large as nine acres have gone dry.

Recent advances such as fracture pattern analysis, borehole imaging, and fracture-flow models will help.

How do I get started?

You need a real expert for well drilling, and even that does not assure that you will hit water, but the odds will be more favorable. If you know a geologist, talk with him or her. Consult a professional well-drilling firm with a California C-57 contractor's license. And remember, once you have your well drilled, pump tests of new wells are necessary to verify the existence of a suitable and sustained water supply. The firm that drilled your well can perform these tests.

For a single family residence, 24 hours of pumping and recovery of the water level to within two feet, or 5% of the static level, depending on the amount of drawdown during pumping, may be adequate. Longer tests are necessary for community supply or industrial wells. Consult with your County well permitting agency for specific water well testing requirements for any type of well.

Where can I get more information?

www.water.ca.gov/groundwater

Integrated Regional Water Management

901 P Street
Sacramento, CA 95814-3515

Northern Region

2440 Main Street
Red Bluff, CA 96080-2398
(530) 529-7300

North Central Region

3500 Industrial Blvd.
West Sacramento, CA 95691
(916) 376-9600

South Central Region

3374 E Shields Avenue
Fresno, CA 93726-6913
(559) 230-3354

Southern Region

770 Fairmont Avenue, Suite 102
Glendale, CA 91203-1035
(818) 543-4600

References

- California Department of Water Resources. *California's Groundwater*. Bulletin 118-2003. 2003.
- California Department of Water Resources. 1990. *Mountain Counties Water Management Studies, Amador County*.
- California Department of Water Resources.. 1983. *Status of Sierra Foothills Water Management Studies*.
- California Department of Water Resources. 1974. *Water Quality Investigation of Western Nevada County*.
- Heath, Ralph C. 1983. *Basic Groundwater Hydrology*. U.S Geological Survey Water Supply Paper 2220.
- Page, R.W.; Anttila, P.W.; Johnson, K.L.; and Pierce, M.J. 1984. *Groundwater Conditions and Well Yields in Fractured Rocks, Southwestern Nevada County, California*. U.S. Geological Survey Water Resources Investigation 83-4262.

